



## How to update firmware

**Firmware update** button in **Device information** menu allows the user to update the device software.



To perform the update:

1. Download the latest software version available on the [www.multicon24.eu](http://www.multicon24.eu) website in **Technical Support** section.
2. Unzip file and copy to a flash drive.
3. Plug in the flash drive.  
Some high capacity pendrives are not supported, best choice is pendrive with 2GB capacity.

Connect **flash drive** to the device.



Enter **Menu** and **Device information** submenu, then move down the scroll bar and start the update process by pressing the **Firmware update** button.



### Note on the update:

- do not power off the device or remove the flash drive from the USB port during the update,
- the update process must go continuously to the end, the user will be informed of the progress throughout the update cycle.

### Attention!

**The user can not start an unfinished update again because this may damage the device.**

- there can not be more than one update file on a flash drive,
- update files must reside in the main folder (root of the drive),
- the update process may take about 5 minutes, depend on the version of the device.